

# Infapower®

## LONG LIFE RECHARGEABLES

### Universal Charger – Model No. C004

**USAGE:** You have the possibility to charge at the same time 1 to 4 pcs. NiCd and NiMH batteries of size AAA, AA, C or D and 1 or 2 pcs. 9V batteries.

**TESTING:** To use this function, the charger must not be connected to the mains. Put the switch to “T”. Put the NiCd or NiMH battery with the correct polarity into the compartment with test position. When the light is on then the battery is not yet empty / discharged. Before you want to charge the battery, it is recommended to discharge it. 9V batteries cannot be tested in this unit.

**DISCHARGING:** Also for this function, the charger must not be connected to the mains. Put 1 to 4 pcs. batteries of sizes AAA, AA, C or D into the battery compartments and put the switch in position “D”. The control light will switch on as long as the batteries are not fully discharged. When all batteries are discharged, the control light will switch off. 9V batteries cannot be discharged with this unit.

**CHARGING:** Put the NiCd or NiMH batteries 1 to 4 pcs. AAA, AA, C, D or 1 to 2 pcs. 9V batteries into the battery compartments. Please pay attention to the correct polarity + or -. Now you can put the switch to position “C” and connect the charger to the mains. The red LED's will switch on and indicate that charging is in process. After the charging process (please observe charging times), disconnect the charger from the mains and take out the batteries.


**CHARGING TIME:**

SIZE	mAh	CHARGE TIME
AA	1300	15 hrs
AAA	700	7 hrs
C	2600	30 hrs
D	2600	30 hrs
9V	170	16 hrs

**CAUTION:**

This charger is intended for use with Nickel Cadmium and Nickel Metal Hydride batteries only. Attempting to charge other types of batteries may cause personal injury and damage to the charger. Indoor use only.

The supply cord of this equipment cannot be replaced. If the cord is damaged, the equipment should be discarded.

Correct Disposal of this product	
	<p>This marking indicates that this product should not be disposed of with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.</p>
Directive 2002/96/EC	